

# Solax Hard Case Lock Setting Instructions

Your Solax Hard Case comes with a combination lock that can be programmed to a 3 digit code of your choice. Please note that the key-hole is for manufacturing purposes only and the case does NOT come with a key.

The combination lock of your hard-case is always set to 000 by default. In order to change the code, undo both latches and open your Solax Hard Case. On the inside of the latch you will notice a little switch with some writing next to it stating "set" and "off". By default the switch will be set to "off" please see image below (switch circled in red).



To select a new combination you will have to switch from off to set. It will take a little bit of force and you should be able to hear a click. Ensure the switch is fully clicked in before proceeding.

Once on set, simply use the dials to select a combination of your choice. Once you are happy with your code, double check that all the digits are properly locked in, turn the latch over and select off.

Now your combination lock has been changed.

Please note, that you will have to repeat the process on both latches.

